



Process Gas Ar Flow Usage Reduction in Aerosol Cleaning

Asha Sharma, Ella Mihevc, Christopher Waitkus,
Tsultrim Tharchin and Silas Scott

April 20, 2016

SPCC 2016
Surface Preparation and Cleaning Conference



Outline

Background

Particle Removal in Cryogenic Aerosol Cleaning

- Effect of process gas on particles

Methods

Throughput Improvements on Ar Aerosol Cleans

- Tuning recipe parameters
- Ar flow usage reduction, process time & throughput

Results

Throughput Improvements on Aerosol clean @ GLOBALFOUNDRIES

- UPH gain and saving (14 nm)



Outline

Background

Particle Removal in Cryogenic Aerosol Cleaning

- Effect of process gas on particles

Methods

Throughput Improvements on Ar Aerosol Cleans

- Tuning recipe parameters
- Ar flow usage reduction, process time & throughput


Results

Throughput Improvements on Aerosol clean @ GLOBALFOUNDRIES


- UPH gain and saving (14 nm)



Particle Removal: Cryogenic Aerosol Clean




Schematic Cryogenic Aerosol Clean



^{1,2}Pressure-temperature diagram Ar:N₂ system

Process parameters

- **Process Gas**
- process gas pressure
- chamber pressure
- **Chuck speed/indexing**
- chuck temperature
- Dewar back pressure




Schematic (redrawn from ¹)

¹Particle Adhesion and Removal, p 460, Wiley & Sons

²ANTARES® System, TEL

Effect of Process Gas

Particle removal efficiency (@ 32 nm)



PRE (Particle removal efficiency)
(calculated from pre-post/pre)

Aerosol Cleaning Force³:

Momentum, $mv = F \cdot \Delta t$

Collision force, $F = V\rho \cdot \frac{v}{\Delta t}$

where, V is volume and ρ is density of cryogenic aerosol

Atomic mass Ar = 39.948 amu

Molecular weight N₂ = 28.0134 amu

- Ar:N₂ mixture will have greater momentum transfer than N₂ only


Summary:

- Particle removal efficiency higher for Ar:N₂ mixture
- Ar:N₂ aerosol - greater momentum transfer than N₂



Effect of Process Gas on Performance

28 nm: Open and shorted via chains




D₀ Reduction (%) by Ar addition

SLO/2LS		MLO/MLS	
O	S	O	S
15	28	52	68

Ar (Ar:N₂) aerosol cleaning shows better opens and shorts performance than N₂ aerosol cleaning

Summary:

- Ar:N₂ aerosol cleaning shows reduced D₀ than N₂




Effect of Process Gas on Performance


28 nm CFM Defectivity, and Yield

CFM


Embedded defect Organic residue 2 Surface flakes 2 Surface particle 2



Defect overlay map - 4 random wfrs



Yield variation ↓ 74%



0.7 % ↑ in HVM Yield

NDDc / normalized defect density counts ↓ > 55 %

Summary:

Ar:N₂ aerosol cleaning show improved inline performance

- NDDc reduction > 55%
- Yield improvement by ~ 0.7%
- Yield variation reduced by ~74%

Outline

Background

Particle Removal in Cryogenic Aerosol Cleaning
Effect of process gas on particles (Sub 28 nm node)

Methods

Throughput Improvements on Ar Aerosol Cleans

- Recipe parameters tuning
- Ar flow usage reduction, process time & throughput

Results

Throughput Improvements on Aerosol clean @
GLOBALFOUNDRIES


- UPH gain and saving (14 nm)



Throughput Improvements on Aerosol Cleans:

Recipe parameters tuning

Engineering Process Parameters



Process	Recipe parameters	T
P1	Indexing, scan speed S1	t1
P2	No-indexing, scan speed S1	t2
P3	No-indexing, scan speed S2	t3

$t1 > t2 > t3$
Scan speed S2 > Scan speed S1

Tuning parameters

- Process time
- Particle removal efficiency
- Throughput

P1 → P2 (~32% process time reduction)

P2 → P3 (~28% process time reduction)


Summary:

- P1 → P3, process time reduction by ~ 60%
- Throughput gain
- Cost of ownership
- Ar flow usage reduction



Throughput Improvements on Aerosol Cleans:

P1, P2, P3: Comparison of True Adders





Summary:

- True adders in, **P1** to **P2** to **P3**, are comparable



Throughput Improvements on Aerosol Cleans

Adders (@ 19 nm) for 14 nm HVM







Summary:

- Comparable adders performance @ 19 nm





Throughput Improvements on Aerosol Cleans:

28 nm product: Via Opens and Shorts



P1 P3

P1 P3



Summary:

P1 and P3 show comparable D_0 (opens and shorts) performance of 28 nm HVM



GLOBALFOUNDRIES®

Outline

Background

Particle Removal in Cryogenic Aerosol Cleaning
Effect of process gas on particles (Sub 28 nm node)

Methods

Throughput Improvements on Ar Aerosol Cleans

- Recipe parameters tuning
- Process time, throughput, Ar flow usage reduction

Results


**Throughput Improvements on Aerosol clean @
GLOBALFOUNDRIES UPH gain and saving (14 nm)**



Throughput Improvements Aerosol Cleans:

UPH Gain and Cost Saving

Engineering Process Parameters



Summary:




P3 implementation at GLOBALFOUNDRIES

- faster throughput
- capable moves
- lowering CoO
- saving on Ar

CapEx saving to date (%)	CoO saving on Ar usage
28%	60%


Throughput Improvements Aerosol Cleans

14 nm product: Via Opens and Shorts



D_0 via opens and shorts are comparable for P1 and P2 process

D_0 -Opens/shorts wafer maps



P1

P3

Summary:

- **P1 and P3** show comparable D_0 (opens and shorts) performance on product
- Faster throughput recipe cleaning performance could be maintained at BEOL cleaning process steps




GLOBALFOUNDRIES®

Throughput Improvements Aerosol Cleans

Impact 14 nm CFM Defectivity

Embedded defects Organic residue Surface flakes Surface particles



Defect overlay map - 4 random wfrs

NDDc (defects) comparable

Summary:

P1 and P3 show comparable inline CFM performance on 14 nm HVM



Summary and Conclusions

Ar (Ar:N₂) aerosol

- Shows reduced D₀ than N₂
- NDDc improvement > 55%
- HVM Yield improvement by ~ 0.7%

Throughput improvement, P3 implementation at GLOBALFOUNDRIES

- Faster recipe on 14 nm HVM
- ✓ Comparable D₀ (opens and shorts)
- ✓ Comparable inline CFM performance
- Increased capacity with same number of tools
- CoO ↓ by ~ 28%
- Ar gas consumption ↓ ~ 60%



Acknowledgements

Grateful thanks to:

- Wet Cleans Colleagues in GLOBALFOUNDRIES***
- Process Integration Colleagues in GLOBALFOUNDRIES***



Questions?



© 2013 GLOBALFOUNDRIES Inc. All rights reserved.



GLOBALFOUNDRIES®